

Louver wall



e-mail: info@zhengte.eu




























































When assembling the shutter walls, Note the side tube direction:

- a: The side pipe hanging out part is opposite the top beam hook
- b: The side pipe hanging out part is the same plane as the top beam hook









If the floor is a wood floor, you don't need to knock in the plastic expansion pipe, directly use J to knock







